




INSTALLATION MANUAL

PRODUCT PARAMETER	
INPUT VOLTAGE	120-277V
COLOR TEMPERATURE	27K/30K/35K/40K/50K
ENCLOSURE	DAMP LOCATION



HARDWARE INCLUDED



A



B



C



D



TOOLS NEEDED (NOT INCLUDED)



Ladder

Drill

Gloves

Safety Glasses

SAFETY INFORMATION

BE SURE THE POWER IS OFF! RISK OF ELECTRICAL SHOCK: Always use the switch to power off. Do not perform any operations while this unit is powered on. The electrical system you want to connect the device to must be grounded. Read the instructions before using or powering this device. The safety instructions must remain with the unit in case of transfer. Any damage to the device linked to an inappropriate use is excluded from support by the warranty. Before connecting, make sure that the current and voltage are compatible with this device. We highly recommend that all installations are made by QUALIFIED ELECTRICIAN. We are NOT responsible by any means for the use or misuse of the following information. We are NOT responsible in whole or part for any harm or damage that may or may not be caused. We reserve the right to revise the components of any product, due to part availability or change ETL, CUL, UL standards without assuming any obligation or liability to modify any products previously manufactured and without notice. These instructions do not cover all details of variations in equipment, nor do they provide every possible contingency to be met. Turn off / unplug power when installing or service device.

WARNING

WARNING: Read all safety precautions and installation instructions carefully before installing or servicing this fixture. Failure to comply with these instructions could result in a potentially fatal electric shock, fire, and/or property damage.

- Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
- Turn off the power when you perform any maintenance.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- All wiring connections should be capped with UL approved wire connectors.

PRE - INSTALLATION

- Carefully remove the fixture from the carton.
- Before beginning assembly, installation, or operation of product, make sure all parts are present. Compare parts with package contents list and diagram on previous page. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.
- Tools required for assembly (Not Included): screwdriver, phillips screwdriver, pliers, electrical tape, wire cutters, safety glasses, ladder, wire stripper.

FCC WARNING


WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTES: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

INSTALLATION (Caution: Before beginning installation turn off the circuit breaker and light switch)

GENERAL WIRING DIAGRAM




INSTALLATION MANUAL

INSTALLATION (Caution: Before beginning installation turn off the circuit breaker and light switch)


SURFACE MOUNTING

STEP 1




Lift the bracket up to the mounted junction box. Align the bracket to the final installation position (and angle), then mark the positions of the screw holes on the mounting surface.

STEP 2




Drill 4 mounting holes in the ceiling at the marked positions.

STEP 3




Feed the AC power supply wires through the center hole of the bracket. Secure the bracket to the junction box with 2 short screws, then fasten the bracket to the ceiling using the 4 provided drywall anchors.

STEP 4




Engage side hook of the fixture into A End of the bracket as shown in the diagram, and fix the safety cable to the bracket.

STEP 5



Make wiring then place all wires and wire nuts into the junction box. Lift up the fixture and pull the fixture slightly toward the Bracket A End to allow the fixture to slide a short distance in the opposite direction. Then press fixture upward on the Bracket B End while releasing the fixture, allowing the fixture to engage and lock securely with Bracket B End.

STEP 6




Wipe away all stains and fingerprints on the panel light surface. Restore power at the circuit breaker and turn the luminaire on to test operation.

FIELD ADJUSTABLE WATTAGE & CCT

The end users may adjust the color temperature and lumen output respectively by the two DIP switches. CCT switch is accommodated with 5 CCT options (2700K, 3000K, 3500K, 4000K, 5000K), and Power switch is accommodated with 4 Power options. The switches can perform the desired color temperature and lumen output combination.

Select a wattage and color temperature by sliding switch left or right respectively to the desired value.



INSTALLATION MANUAL**INSTALLATION** (Caution: Before beginning installation turn off the circuit breaker and light switch)**ADDITIONAL ACCESSORIES**

- DC Sensor





Fig. 1




Fig. 2




Fig. 3




Fig. 4

INSTALLATION

1. Remove the sensor receptacle plug. (Fig. 1)
2. Plug sensor to the receptacle. (Fig. 2)
3. Rotate the sensor and align its edge to receptacle to ensure that it's installed securely. (Fig. 3 & Fig. 4)